


Assembly instruction for AKO pinch valve (flange type) Series V+VF DN 100 to 250 mm



Removing the old sleeve

Loose bolts (C), take off flanges (B).
Pull out old sleeve (D) by using a pipe wrench.
If helpful, spread AKO mounting paste (MP200) between rubber and internal body surface.
Clean all valve parts and inspect for wear.

Installation of the new sleeve

Picture 1

Spread following parts with AKO mounting paste (MP200):

- inside and outside surfaces of sleeve (D), cones of flanges (B) and inside surface of body (neck area).

Caution: Do not use any grease or oily paste!

Picture 2

Push sleeve (D) into body (A) until it is centred.

Picture 3

Assemble flange (B) onto body and fix it with 2 or 4 mounting bolts (C), washer and nuts. Tighten them counter clockwise until flange cone touches the sleeve.

Picture 4

Put opposite side of flange (B) into sleeve (D) and tighten second bolt (C), washer and nut until it touches the sleeve.

Picture 5

Push mounting pipe into the valve (5/6 length of the sleeve).

Put 4 bar air through the air inlet to pressurize the sleeve.

Picture 6+7

Use a spanner and push the sleeve behind the cone from the flange (B). Tighten mounting bolts from second flange (B) and assemble completely with the remaining bolts (C). Bolts have to be tightened. Release control air. Assemble counter flange as described in picture 5, 6+7. Again, release control air and remove mounting pipe. Make sure that all mounting bolts have been replaced by assembling bolts (C). Verify bolts are tight.

Picture 8

Put mounting wood into valve assembly, with the small part facing to the air inlet.

Pressurize valve with 4 bar and keep the wood in stable position. Sleeve must close in "lip-shape" position viewing to air inlet.

Alternatively assembly: Valve can be assembled under a mechanical press.

Caution: Do not use any sharp tools during assembly, it may damaged valve parts!

*Replacement-/ Maintenance parts: Sleeve (D) and flanges (B).

Assembly tool: AKO mounting set (i.e. W125) consists of mounting paste, mounting pipe, mounting wood, assembling screws, nuts and bolts.



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Picture 6



Picture 7



Picture 8

AKO UK Ltd

13 Alvis Way • Daventry • Northants • NN11 5PG • Tel: 01327-312747 • Fax: 01327-312565
e-Mail: sales@ako-valves.com • Web: www.ako-valves.com